

OPEN FIRST!!



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts list for Master set # 3-18130 1993-01 CAMARO / FIREBIRD

© 2003 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's Polyurethane.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Torque arm mount bushing set: 3.1111

- 1 - 1040 bushing
- 1 - 17126 installation instructions

Front end control arm bushing set: 3.3164

- 2 - 3261 lower control arm pivot bushing, horizontal position thrust washer
- 2 - 3262 lower control arm pivot bushing, horizontal position
- 2 - 3263 lower control arm pivot bushing, vertical position center
- 2 - 3264 lower control arm pivot bushing, vertical position upper
- 2 - 3265 lower control arm pivot bushing, vertical position lower
- 4 - 3266 upper control arm pivot bushing
- 4 - 15.10.137.39 (3/4"O.D. x .480" I.D. x 1.570 sleeve)
- 1 - 17138 installation instructions

Rear end control arm bushing set: 3.3136

- 4 - 15.12.07.* lower control arm pivot bushing assembly (3021 bushing / 15.02.09.39 "I" shell / 15.10.10.39 (3/4"O.D. x 1/2" I.D. x 2.425 sleeve)
- 4 - 3232 thrust washers.
- 1 - 17041 installation instructions
- use 17019 installation instructions

Rear panhard bar bushings set: 3.7106

- 4 - 2042 pivot bushing
- 2 - 15.10.101.39 (3/4"O.D. x 9/16" I.D. x 1.875 sleeve)
- 1 - 17039 installation instructions

Parts list continued:

Front swaybar bushings: 3.5163

- 2 - 5288 bushings (30mm I.D.)
- use 17039 installation instructions

Front Swaybar end link set : 9.8118

- 2 - 15.12.02.* End link assembly
- Note: 1 assembly has 4 4806 bushing, 1ea 15.10.23.39 sleeves, 4ea 15.03.01.39 washers, 1ea 15.05.04.39 bolt, 1ea 15.07.01.40 nut.
- use 17039 installation instructions

Rear swaybar and endlink bushing set: 3.5161

- 2 - 5335 bushings (19mm)
- 2 - 15.12.06.39 bushing bracket
- 4 - 15.03.23.39 flat washer
- 8 - 4806 endlink grommets
- 2 - 15.10.63.39 (9/16"O.D. x 3/8" I.D. X 2.200 sleeve)
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.05.03.39 (3/8"-16 x 6" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)
- 1 - 17145 installation instructions
- use 17039 installation instructions

Tie-rod boot sets: 9.13101

- 2 - 13001 tie-rod boot set

Grease: Formula 5 Prelube.

- 3 - 9.11101 grease tubs.
- (See our catalog for more details).

17387

26/MAR/03 BRH
Updated 1/JUL/03 BRH

B.O.M. for master set # 3.18130

Torque arm mount bushing set: 3.1111

- 1 - 1040
- 1 - 17126 installation instructions

Front end control arm bushing set: 3.3164

- 2 - 3261
- 2 - 3262
- 2 - 3263
- 2 - 3264
- 2 - 3265
- 4 - 3266
- 4 - 15.137 (3/4"O.D. x .480" I.D. x 1.570 sleeve)
- 1 - 17138 installation instructions

Rear end control arm bushing set: 3.3136

- 4 - 15.12.07.*
- 4 - 3232
- 1 - 17041 installation instructions
- 1 - 17019 installation instructions

Rear panhard bar bushings set: .7106

- 4 - 2042
- 2 - 15.10.101.39 (3/4"O.D. x 9/16" I.D. x 1.875 sleeve)
- 1 - 17039 installation instructions

Parts list:

- 1 - 17387

Parts list continued:

Front swaybar bushings: 3.5163

- 2 - 5288 bushings (30mm I.D.)

Front Swaybar end link set : 9.8118

- 2 - 15.12.02.*

Rear swaybar and endlink bushing set: 3.5161

- 2 - 5335 bushings (19mm)
- 2 - 15.12.06.39 bracket
- 4 - 15.03.23.39 flat washer
- 8 - 4806 endlink grommets
- 2 - 15.10.63.39 (9/16"O.D. x 3/8" I.D. X 2.200 sleeve)
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.05.03.39 (3/8"-16 x 6" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)
- 1 - 17145 installation instructions

Tie-rod boot sets: 9.13101

- 2 - 13001 tie-rod boot set

Grease: Formula 5 Prelube.

- 3 - 9.11101 grease tubs.

All sleeves and instructions for each set must be packaged together in individual bags.

Fold the Master parts list so the

OPEN FIRST!!

**Parts list for
Master set # 3.18130
1993-01 CAMARO / FIREBIRD**

is clearly visible when packaged on skin card.

3.18130.cdr
26/MAR/03 BRH

PACKAGE IN MASTER SET BOX