Installation Instructions



Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

SPORTLINE Kit - #4.0138

CHEVROLET, Camaro, V8 (Incl. Z28 & Convertible) 1982-1992 PONTIAC, Firebird, V8 (Incl. Trans AM & Convertible) 1982-1992

Kit Contents	Description	Part Number	Qty	
	Front Spring	4.0138F	2	
	Rear Spring	4.0138R	2	
	Information Kit	EPAK	1	
	Instructions	4.0138INST	1	

NOTES: Read All Instructions Before Beginning Installation

- Installation of a SPORTLINE Spring set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- . Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- **SPORTLINE** Springs are marked with the letter F and R (located at the end of the part number) designating front and rear springs.
- **SPORTLINE** Springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **SPORTLINE** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

ALIGNMENT:

After installation, it will be necessary to perform a full vehicle alignment using factory specifications.

