

Part Number: 3500770

**Product** 

Description: BRACKET SOL PACK SMITTYBILT GEN2 X20 SUIT 98510

# ARB 4x4 ACCESSORIES

## Corporate Head Office

42-44 Garden St Kilsyth, Victoria **AUSTRALIA 3137** 

+61 (3) 9761 6622 Tel: Fax: +61 (3) 9761 6807

Australian enquiries North & South American enquiries Other international enquiries

sales@arb.com.au sales@arbusa.com exports@arb.com.au

# www.arb.com.au

#### REQUIRED TOOLS FOR FITMENT OF PRODUCT:

**BASIC TOOL KIT** 

#### HAVE AVAILABLE THESE SAFETY ITEMS WHEN FITTING PRODUCT:

Protective eyewear



**Hearing protection** 



NOTE: 'WARNING' notes in the fitting procedure relate to OHS situations, where to avoid a potentially hazardous situation it is suggested that protective safety gear be worn or a safe work procedure be employed. If these notes and warnings are not heeded, injury may result.

## FASTENER




### **TORQUE SETTINGS:**

SIZE	Torque Nm	Torque lbft
M6	9Nm	7lbft
M8	22Nm	16lbft
M10	44Nm	32lbft
M12	77Nm	57lbft

PARTS LISTING				
APPLICATION.	PART NO.	QTY	DESCRIPTION	
BRACKET TO SOLENOID BOX	3759529	1	BRACKET WINCH CONTROL BOX	
	6151281	4	SCREW M5x12 PAN HEAD	
	4584337	4	WASHER SPRING M5	
	4584338	4	FLAT WASHER M5x12x1	

Last Rev Date: 15/12/2014 Page 1 of 2 Copyright © 2005 by ARB Corporation Limited. All rights reserved, this document must not be reproduced without the express authority of ARB Corporation Ltd

### **FITTING PROCEDURE**




- 1. The mounting bracket features the following mounting holes:
  - A- Slotted holes for solenoid box bolts.
  - B- Offset bullbar mounting slot.
  - C- Centre bullbar mounting slot.


Use the following to mount the bracket to the box.

D- M5x12 Screw, Spring Washer & Flat Washer.





2. Turn over Smittybilt control box. Remove the Smittybilt mounting brackets.



- Fasten bracket to box using M5x12 screw, spring washer and flat washer supplied. The bracket can be rotated in 180° increments to allow the placement of power cables and control input in the position suited to your application.
- 4. Fit bullbar supplied mounting bolts to either one of the main mounting slots first (slot B or C).



5. Fit to vehicle using fasteners supplied with bullbar.