

M-6014-BOSS Cylinder Head Stud Kit INSTALLATION INSTRUCTIONS

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD RACING PERFORMANCE PARTS.

Please visit www.fordracingparts.com for the most current instruction information

!!! PLEASE READ ALL OF THE FOLLOWING INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION. AT ANY TIME YOU DO NOT UNDERSTAND THE INSTRUCTIONS, PLEASE CALL THE FORD RACING TECHLINE AT 1-800-367-3788 !!!


BOM

Description	<u>Quantity</u>
4.060 OAL stud	10
5.750 OAL stud	10
Hardened washer	20
12pt. ½ - 20 nut	20

INSTALLATION INSTRUCTIONS

Before installing cylinder heads for final assembly:

- **STEP 1:** Loosely assemble and check for interference between the exterior head studs and exhaust header(s).
- **STEP 2:** Install studs into block and torque to 3-5 lb ft.
- **STEP 3:** Install head gasket.
- STEP 4: Install cylinder heads.
- **STEP 5:** Install washers (10 per side).
- **STEP 6:** Lubricate ¹/₂"-20 thread with engine oil (lightly).
- **STEP 7:** Install nuts (10 per side).
- STEP 8: Torque in 3 steps:
 - (1) Tighten all nuts in sequence to 35 lb ft \pm 5.
 - (2) Tighten all nuts in sequence to 65 lb ft \pm 5.
 - (3) Tighten all nuts in sequence to 100 lb ft +/- 5.



Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356

Techline 1-800-367-3788

Page 1 of 1

IS-1850-0302