



Mounting Instructions for KC 1130, 1131, 1132 & 1133 Replacement KC Fog Lights on Jeep Wrangler 97 - 06

Thanks for choosing a KC HiLiTES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950.

The enclosed KC fog light is intended to replace the factory fog light and utilize the Jeep factory wiring that came with the vehicle.

Follow these few simple steps and you will have your lights working in no time at all.

MOUNTING & AIMING...

1. If you are replacing a Jeep Factory light, unplug it from the harness and remove it from the vehicle.
2. Your new KC fog light has a larger bolt than the Jeep

factory light so the hole in the bumper must be drilled out to 10mm or 13/32".

3. Mount the light on the bumper in the newly drilled hole. Plug the light into the factory harness.
4. Aim your fog light so the beam pattern shines just below your headlight low beams.
5. You're Done!

If you are installing two new lights, repeat the procedure for the second light.



**IF YOU HAVE ANY PROBLEMS OR QUESTIONS, PLEASE
CALL CUSTOMER SERVICE AT 800-528-0950**