

2018+ JEEP WRANGLER JL / GLADIATOR JT

JEEP JL/JT HEADLIGHT INSTALL GUIDE

The KC Jeep Wrangler JL/Gladiator JT Gravity ® LED Pro 7" DOT Headlights (SKU #42342) include all necessary brackets, wire adapters, and hardware. These are designed to replace the factory headlights and mount to the factory locations for an easy, bolt-on install.

WARNING: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



Parts Included:

QTY 2 - Gravity ® LED Pro 7" DOT Headlights

QTY 2 - Headlight brackets

QTY 2 - Protective isolator gaskets

QTY 2 - Wire harness adapters



Use the camera app on your phone to scan the image to the left to view the video version of this Install Guide.

TOOLS NEEDED FOR INSTALLATION

SOCKETS





INSTRUCTIONS FOR INSTALLATION



1. ASSEMBLE SMALLER BRACKET

- Unscrew the smaller front bracket from the larger rear bracket.
- Install the rubber ring onto the smaller bracket and align the tabs.
- Ensure the rubber tabs are underneath the metal tabs on the smaller bracket.

JEEP WRANGLER JL/GLADIATOR JT OVERHEAD LIGHT



2. SLIDE SMALL BRACKET ONTO HEAD-LIGHT

- Determine the top of the smaller bracket (shown in image on left) and then slide the smaller bracket and rubber piece over each headlight.
- Drop headlight and smaller bracket into larger bracket to create the headlight assembly. Ensure the rectangular tabs on the back of the headlight line up with the tabs on the brackets.



3. REMOVE GRILLE AND HEADLIGHTS

- Remove the grille by using a flathead screwdriver or panel remover tool to remove the plastic retainer clips along the top of the grille.
- Pull the grille firmly away from the vehicle underneath each headlight and along the bottom to release the pressure fit clips.
- Remove the factory headlights with the three bolts, and unplug.



4. INSTALL KC HEADLIGHTS AND GRILLE

- Connect the wire adapter to the KC Headlight and the factory wire harness.
- Install your new KC Gravity ® LED Pro 7" DOT Headlight assembly into the factory bolt holes.



- To aim the headlights, only install one headlight at a time, and then aim the first one in line with the factory headlight cutoff beam.
- Install the second headlight, aim it, and then reinstall the grille and plastic retainer clips.

PRODUCT REGISTRATION

Thank you for becoming part of the KC HiLiTES family and purchasing one of our premium KC products! With over 45 years of history in the auxiliary lighting market, you have become a part of our ever growing family, and we encourage you to register your product online at HTTP:// REGISTER.KCHILITES.COM to ensure you get all the benefits of owning a KC HiLiTES product.