

# **T-REX**

## **Billet Grilles**

20896

**05-08 TOYOTA**

**TACOMA**

20896

**05-08 TOYOTA**

**TACOMA**

**2 PC SIDE VENTS**  
**BILLET INSERT**

### **Tools Required:**

Phillip Screw Driver  
Drill – 1/16 Drill Bit

### **Hardware / Parts List:**

2 - Billet Insert (9 bars)  
2 - #8 X 1 Screws (# 6 Head)

## **Read and understand instructions before attempting installation**

### **Step 1**

Test fit the billets into the side openings. Each billet has a mounting tab welded to the rear of the billets. Mark the mounting hole to the openings. Remove the billets. Drill a 1/16" pilot hole for the mounting screws.

### **Step 2**

Re-center each billet and secure the billets using the screws provided.

***Thank you for purchasing your T-Rex billet grille.*** T-Rex Truck Products Inc. 1/17/05