

44910
46910
2013 TOYOTA
AVALON



44910
46910
2013 TOYOTA
AVALON

2013 TOYOTA AVALON

Sport Grille
Install time: 20 Mins.

TOOLS REQUIRED:

Pliers

PARTS LIST:

(2) Grilles

(8) V-Clips

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

- Remove Clips to get behind the Factory Grille.
 - Place the Grille over the Factory Grille. (Fig. 1)
 - From behind the Grille, Place the V-Clips onto the Brackets that are on the Mesh Grille, with Pliers, clamp the V-Clips. (Fig. 2)
- Repeat for remaining V-Clips

INSTALLATION COMPLETE

