

51032/54032

2014 CHEVROLET CAMARO RS



51032/54032

2014 CHEVROLET CAMARO RS

2014 CHEVROLET CAMARO RS

Upper Class Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flat/Phillips Screwdrivers

PARTS LIST

- (1) grille
- (4) 6/32" Nylon Lock Nuts
- (4) 2" Bone Bracket
- (4) 10/32" Washers
- (4) 2" Black PVC Tubing



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Radiator Cover Removal & Grille Installation

Open the hood on the vehicle. Now remove the four 10mm bolts from the top of the radiator cover plate (Fig 1). Now remove six plastic pop clips that hold the radiator cover and the bumper cover together (Fig 2). Now remove the radiator cover plate (Fig 3) this will give you access to the rear of the factory grill. Slide the four pieces of black pvc tubing onto the threaded studs that are welded to the back of the mesh grille. Insert the mesh grille onto the factory grill opening (Fig 4). Take the two bone brackets and reach down behind the mesh grille and insert them onto the threaded studs on the back of the mesh grille (Fig 5). Slide the washers over the threaded studs along with the nylon lock nuts and tighten. Reinstall the radiator cover. Installation complete. Thank you for purchasing a T-REX Grille.



Fig 1



Fig 2



Fig 3



Fig 4



Fig 5