

55187, 52187
55186, 52186
10-13 CADILLAC
SRX



55187, 52187
55186, 52186
10-13 CADILLAC
SRX

10-13 Cadillac SRX Mesh Bumper

TOOLS REQUIRED:
Socket & Ratchet Set
Screwdriver Set
3/4 Drillbit & Drill

PARTS LIST
(1) Bumper Grille
(4) L-Brackets
(4) 6/32 Nylon Lock Nuts

BUMPER GRILLE REMOVAL

- With a 3/4 Drillbit, Drill through the center of the Screws on the License Plate and remove. (Fig. 1)
- Remove 3 Silver Bolts towards the end of the Bumper Cover. (Fig. 2)
- Remove 2 Clips from each Side Fender Well. (Fig. 3)
- Remove 12 Bolts on the Inner Bumper Shell between the Outer Bolts. (Fig. 4)

BUMPER GRILLE INSTALLATION

- Place Mesh Grille Through the Factory Bumper Opening. (Fig. 5)
- From behind, Place an L-Bracket on the Threaded Studs on the Mesh Grille and Tighten with provided 6/32 Nylon Lock Nuts. (Fig. 6)

INSTALLATION COMPLETE

