

54767**10-12 NISSAN
ALTIMA SEDAN****54767****10-12 NISSAN
ALTIMA SEDAN****10-12 NISSAN ALTIMA SEDAN****Upper Class Mesh Grille****TOOLS REQUIRED:**

Socket and Ratchet Set
Flathead/Phillips Screwdrivers

PARTS LIST

(4) Factory Clips
(5) 6/32" Flat Washers
(5) 6/32" Nylon Lock Nuts
(2) 1/4"X1" Bolts
(2) 1/4" Lock Washers
(2) 1/4" Flat Washers
(2) 1/4" Nuts
(1) Mesh Grille & Top Plate

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Factory Grille Removal

Remove the six plastic pop clips on the top of the radiator cover with a flat screwdriver (Fig 1). Unlatch two latches on the top corners of the factory grille, they hold the grille to the bumper cover (Fig 2). Pull the top of the factory grille forward and reach behind the factory grille. There are six plastic latches holding the factory grille to the bumper cover along the bottom edge of the factory grille. Use your hands and a flat screwdriver if necessary to unlatch these six latches. The factory grille should now be loose and you can fully remove it (Fig 3). If you purchased a bumper mesh grille install it at this time.

Step 2 Mesh Grille Installation

Take the top plate and install it onto the mesh grille, the bent tabs on the top plate will bend downward on the mesh grille. Install the 6/32" flat washers and 6/32" lock washers on each threaded stud along with a nylon lock nut and tighten (Fig 5). Install the four clips in the parts bag onto the four tabs along the bottom of the mesh grille (Fig 6). Now install the mesh grille into the factory grille opening, the bottom tabs on the mesh grille will install into the factory grille lower slots. There are two round holes and a square hole in the top plate, install the factory hood retention clip in the square hole. Take the 1/4" bolts and install the 1/4 lock nuts and 1/4 flat washers onto them and insert them through the round holes in the top plate and the bracket on the vehicle with a hole in it. On the backside install the 1/4" nuts to secure the top plate (Fig 6). Installation complete.



Fig 1



Fig 2



Fig 3



Fig 7



Fig 6



Fig 5