

55938
52938
12-13 TOYOTA
TACOMA



55938
52938
12-13 TOYOTA
TACOMA

12-13 TOYOTA TACOMA

Upper Class Mesh Bumper Grille

Install time: 20 Mins.

TOOLS REQUIRED:

Socket Wrench

PARTS LIST:

- (1) Bumper Mesh Grille
- (4) 2" J-Hooks
- (4) 6/32 Nylon Lock Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

IF YOUR HANDS REACH FROM BEHIND THE BUMPER SKIP TO FIG. 2

- Remove 2 Bolts and 1 Clip along the top of the Factory Grille. (Fig.1)
- Unclip 8 Clips along the Bottom of the Factory Grille to Remove.
- Bend the Top Threaded Studs on the Mesh Grille a bit. (Fig. 2)
- Place Bumper Grille onto the Factory Bumper Opening. (Fig. 3)
- From behind the Bumper Opening, Place a J-hook on the Threaded Stud to Latch onto the Factory Bumper Grille, Tighten with provided Nylon Lock Nuts. (Fig. 4)

Installation Complete

