

6311111
07-13 CHEVY
SILVERADO 1500



6311111
07-13 CHEVY
SILVERADO 1500

07-13 CHEVY SILVERADO 1500

Torch Series Grille 1 Pc.

For off-road use only

TOOLS REQUIRED:

10mm Socket and Ratchet
 Flat/Phillips Screwdrivers

PARTS LIST:

(4) Metal Clips (20860)
 (9) #10 Flat Washers
 (9) 10/32" Nylon Lock Nuts
 (1) Torch Series 1 Pc. Grille
 (2) Upper and Lower Plates

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Test fit the grilles into the openings. Remove the radiator cover from the vehicle; then the four 10mm bolts along the top of the grille. The grille has metal clips along the bottom and center (Fig 1); these secure the grille to the core support. Use a slotted screwdriver to release the clips. Remove the grille. If you have purchased the lower grille; install grille now.

Step 2

Install the upper and lower grille plates to the new grille using the provided washers and nylon lock nuts. Locate the new metal clips and place these on the lower grille mounting plate tabs. Center the grille into the opening. Place the lower tabs into the factory mounts making sure that they completely clip in (Fig 2). Align the top plate holes to the factory upper bolt location. Install the bolts and tighten the nuts until the grille is held in place (**DO NOT TO OVER-TIGHTEN**).

