



Granatelli Motor Sports, Inc. - 1000 Yarnell Place - Oxnard, CA 93033-2454
805-486-6644, Ext. 23 (Service Dept.) - 805-486-6684 (Fax) - Hours: M-F 8AM-5PM (PST)
www.GranatelliMotorSports.com/techsupport.htm - techsupport@GranatelliMotorSports.com

Installation Instructions P/N 500000

Thank you for purchasing Granatelli Signature Series rear control arms. Our control arms feature precision mig welds, heat treat DOM (drawn over mandrel) tubing, durable powder coated finish, greasable urethane bushings, and premium hardware. Like all Granatelli Motor Sports products, great pride and precision craftsmanship went into making this kit.

1. Begin by jacking up the rear of the car, place jack stands under rear end housing.
2. Loosen and remove the front rear bolts from the control arm on one side of the car only.
3. Remove the control arm and replace with the Granatelli Signature Series control arm making sure that the grease fittings are pointed down.
4. Re-install and tighten the bolts in control arms.
5. Repeat this procedure for the opposite side. Your installation is now complete.

NOTE: DUE TO THE NATURE OF THIS PRODUCT, IT IS REASONABLE TO EXPECT SOME INCREASE IN ROAD NOISE!