



**PART #3263**  
**TORQUE-CURVE**  
**MPFI SPACER KIT**  
2005-06 FORD MUSTANG  
4.6L 3 VALVE V8

## INSTALLATION INSTRUCTIONS

**Important!** Read all instructions before you begin installation.

### THIS KIT CONTAINS

- 1 - Hamburger's Perf. Spacer
- 4 - 6mm Washers
- 1 - Throttle Body Gasket
- 4 - 6mm X 60mm Bolts

### TOOL LIST

- 8mm Socket
- 10mm Socket

- 1. DISCONNECT NEGATIVE (-) BATTERY CABLE.**
- Loosen the hose clamp and remove the air tube from the throttle body, and move it aside.
- Remove the four mounting nuts on the throttle body, and slide the throttle body off the studs.
- Using two of the nuts just removed, remove the four factory studs. Using this "double nut method", instead of pliers, prevents damage to the studs, so they can be reused.
- Clean the surface of the intake manifold and throttle body. Be sure not to damage the factory O-ring seal.
- Using the four 6mm x 60mm bolts, 6mm washers and gasket provided in this kit, mount the Hamburger's spacer between the throttle body and the manifold. (Note: Follow the directions on the backside of the spacer for correct spacer orientation.) The gasket installs between the throttle body and the Hamburger's Spacer. Tighten all four bolts evenly to ensure proper seal.
- Reinstall the air tube onto the throttle body and tighten the hose clamp.
- Reconnect negative battery cable.



Manifold with Throttle Body & Two Studs Removed

Installation Completed

12438 Putnam Street • Whittier, CA 90602 tel (562) 921-0404 • fax (562) 921-7515  
website: [www.hamburgersperformance.com](http://www.hamburgersperformance.com) • email: [techsupport@tdperformance.com](mailto:techsupport@tdperformance.com)

©2007 TORQUE-CURVE, INC.