



620.221.2268 – 800.344-8759 – (Fax) 620.221.7423 – P.O. Box 815 – Winfield, KS 67156

ALUMINUM TAILGATE INSTALLATION INSTRUCTIONS FOR DODGE TRUCK APPLICATIONS

- **#15320--All 1994-2001's and 2002 2500/3500 Series**
- **#15330--2002 1500 Series, 2003-2008 1500/2500/3500 Series and 2009 2500/3500 Series**
- **#15340--2009 1500 Series**
- Before beginning tailgate installation, check the carton you have received to make sure it is not damaged. If there is visible damage, refer to the "DAMAGED" label on the carton for instructions. Next, verify that the carton label reflects the correct part number/application listing for your vehicle and further verify that you have the correct part by referencing the part label located on the bottom of the tail gate.
- To begin installation, detach the support cables from the factory tailgate (leaving them attached to the truck bed). Remove the tailgate from the truck bed by positioning the tailgate approximately half open (about 45 degrees) and gently pulling it away from the vehicle.
- Install your new Husky Liners tailgate in the same manner the factory tailgate was removed. Once installed, attach the original Dodge tailgate support cables to the lower most bolt on each side of your Husky Liners tailgate. **Note: On Dodge trucks using Husky Liners tailgate part #15320 (all 1994-2001's and 2002 2500/3500 series) and part #15340 (2009 1500 series) you will need to twist the support cables 180° before attaching. This "twist" will allow the support cable to clear the edge of tailgate when it is closed.**
- Finally, adjust the striker pins up/down/forward/backwards as needed to provide for a smooth and complete latch operation (loosen/tighten with a Torx® wrench).
- **CARE AND USE:** Your Husky Liners aluminum tailgate is **Bright Coat Finished** for years of good looks. Maintain it as you would the painted areas of your truck (wash and wax). DO NOT use abrasive polishes or chrome cleaners.