



Information and Installation

762 Bonham Avenue • Columbus, Ohio 43211

Phone: 1-800-345-4545 • FAX (614) 299-4444

Jegster 1979-93 Mustang Welded Drive Shaft Loop Kit • 550-40733

Jack up the car and support it with jack stands. Unbolt the rear of the driveshaft to slide the loop in place. The longest bracket goes to the drivers side. Lift the carpet in order to drill the floor. Slide the loop into place and drill two holes through the bracket on each side and install the bolts with flat washers through the top of the floor. Tighten securely and reassemble the drive shaft.

Your Kit Includes

- 1...Driveshaft Loop Assembly
- 4...Flat Washers
- 4...Bolts
- 4...Nuts