

## **Installation Instructions for 15121 Cool Can with the JEGS “Just-A-Ble” Integral Mounting System**

*The JEGS “Just-A-Ble” mounting system is extremely easy to use.*

1. Simply drill two 1/4” holes with clearance. Use a letter “F” drill bit (.2570”) or 17/64 drill bit (.2656”) in your selected mounting position. Do not drill the mounting holes closer than 1” centers or further apart than 5” centers.
2. Place one each of the stainless steel lock and flat washers onto the stainless steel bolt and insert the assembly through the drilled hole. Start a stainless steel nut onto the bolt and repeat for the second mounting hole.
3. Slide the cool can’s mounting slot over the exposed nuts (Suggestion: spray a light coating of silicone or equivalent product on the surface of the nut or bolt head to aid in the installation) and position the cool can in the desired location and tighten the bolts.
4. Optional: You can also mount the bolts in the reverse direction with the head of the bolt in the “Just-A-Ble” slot.

