

## ***Installation Instructions for 15798 & 15799 Accelerator Linkage 68-69 Camaro***

### **Installation Instructions:**

1. Attach the Pedal Rod Support to the firewall in the factory location.
2. Install the E-Clip onto the Pedal Rod.
3. Lubricate the Pedal Rod with grease before inserting it into the Pedal Rod Support.
4. A unique feature of the Throttle Lever and Pedal Rod is that the connection between the two utilizes a spline. This allows fine adjustment of the Throttle Lever location. Start with installing the Throttle Lever in the stock location; then adjusting to the desired location.
5. Make sure the linkage moves freely in the Pedal Rod Support without binding. Be sure to have adequate side-to-side movement/play.
6. Tighten the #8-32 screw on the Throttle Lever. Check for proper operation before driving the vehicle.

