

Installation Instructions for 31151, 31152, 31161 & 31162 2011 Ford Mustang GT 5.0L 4V Exhaust Kit

Kit Includes:

- | | |
|---|---|
| 2) passenger & driver side S-bend extension # 1429046 | 2) passenger & driver side over the axle pipe # 1429051 |
| 1) passenger side muffler #1429048 | 1) driver side muffler #1429049 |
| 6) # A30BF 3" clamps s/s | 1) # 1429052 H-pipe |

DANGER WARNING: Should the purchaser decide to install this exhaust product at home, be warned that pleasure car or light duty truck/van "bumper" jacks are intended for emergency use only. The use of frame contact jack stands in conjunction with a floor jack as main support is highly recommended to minimize accidental dropping of a vehicle while the installation proceeds.

Limitation of liability--Disclaimers: The regulation of emissions production, noise levels and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns and counties.

The manufacturer makes no warranties of merchantability, of fitness for a particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations or ordinances in the states where they may be sold to the ultimate purchaser, the consumer.

The entire risk as to the conformity of this product in any such state and as to repair, should the product prove to be defective or nonconforming, is on the retail purchaser, the buyer, the ultimate consumer of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, and or repair. The foregoing statement limits the liability of the manufacturer.

Instructions:

NOTE: DO NOT TIGHTEN ANY BOLTS OR CLAMPS UNTIL THE LAST STEP!! You will need to reuse the (4) O.E. clamps; they are fastened to the original mufflers with a small tab and will need to be removed. This can be accomplished by wiggling the clamp back and forth to break the tab.

1. Disconnect the battery (this will allow the vehicles computer to reset and read the new exhaust system).
2. Support the vehicle in a safe manner, using a shop hoist or frame contact jack stands on a level surface. Remove the exhaust at the clamps behind the converters; you will need to reuse these clamps. Leave the O.E. rubber hanger mounts on the car, as well as the O.E. mufflers, unless you will be also installing an additional axle-back system (now is a good time to do so though!!).
3. Install the driver side (left) over the axle pipe to the muffler using a 3" clamp. These are the same for driver and passenger side.
4. Repeat step 3 for the right (passenger) side.
5. Install the driver side (left) muffler to the H-pipe using a 3" clamp, the outlets of the mufflers both have an over the axle elbow welded on.
6. Repeat step 5 for the right (passenger) side.
7. Install the H-pipe to the S-bend extensions using the new 3" clamps.
8. Install the driver and passenger side S-bend extensions to the O.E. converters using the original clamps. The inlet of both ends has the flare, and they route the exhaust in towards the drive shaft. These are the same for both the driver and passenger side.
9. Once the new pipes are hooked up to the O.E. hangers, connect the over the axle pipes to the rear mufflers (or install the new axle-back kit), using the original clamps.
10. Check for clearance of the frame, body, suspension members, and of all brake and fuel lines. When you are satisfied with how the system hangs, tighten the clamps, torque the new Accuseal clamps to 45-60 ft. lbs, the original clamps to 20.65-23.6 ft. lbs. Reconnect the battery.



1-800-345-4545 jegs.com

