

## ***Installation Instructions for 40375 & 40377 Billet Aluminum Wire Loom Sets***



- Step 1.** Identify Left and Right sides. The Squared end will be in the rear, closest to the Distributor.
- Step 2.** Remove the (2) small Phillips screws holding the wire retainer together.
- Step 3.** Open small hardware package. There should be (4) aluminum slide brackets, (8) each of Phillips screws, flat washers and lock nuts.
- Step 4.** Insert Phillip Screw on the Inside hole of wire retainer, place the aluminum slide bracket on the bottom of bracket, using flat washer and lock nut secure in place. Do not tighten as you will need to make adjustments forward or back.
- Step 5.** Repeat process on next set of holes on the retainer bracket. Note: there are various positions for you to be able to mount the bracket depending upon engine application.
- Step 6.** The Aluminum slider bracket will now attach to the engine by way of Valve Cover Bolts. Remove your bottom (2) Valve cover bolts and insert the bolt thru the hole on the aluminum slider bracket.
- Step 7.** Once everything is in place then snug the bracket hardware down. Place the wires in the wire retainer. Place the top piece of the retainer on and tighten the (2) Phillip screws.
- Step 8.** Repeat this for the opposite side.