

## **Installation Instructions for 52060 to 52066 Fan Shrouds**

### **Install Instructions:**

1. The shroud consists of four sides, two long sides (top & bottom) and two short sides (right & left). Using the supplied rubber trim slide one each onto the right and left sides (short sides). You may have to cut off any excess trim.
2. The top and bottom (long sides) of the shroud uses a small flange to fasten to the radiator. Mark four(4) holes evenly spaced across the top and bottom flange of the shroud. Using a #7 bit drill the eight(8) holes you just marked.
3. Mount electric fan to the shroud. If you purchased a JEGS electric fan the shroud is pre-drilled for mounting. If you are using your own electric fan, center the fan on the shroud in the desired orientation, mark and drill the shroud for your electric fans mounting configuration. It is suggested to use stainless steel bolts, washers, lock washers & nuts (not supplied) to secure the electric fan to the shroud.
4. The shroud is going to mount to the flange at the top and bottom of your radiators core. Using the shroud as a template center the shroud on the radiators core. Using the holes drilled in step 2 above mark and drill the flange on the top and bottom of your radiators core with a #7 bit.
5. Using the included hardware securely fasten the shroud to your radiator.

