

## **Installation Instructions for 61540 & 61541 Quarter Stick Cover**

### **Installation Instructions for Solenoid Shift Kit:**

1. Install four (4) rubber grommets in cover.

**NOTE:** If a mounting plate is used, rubber grommets may need to be trimmed.

2. Remove neutral safety switch retaining pin.
3. Slide cover over shifter.
4. Insert short quick release pin in the narrow end of the shifter, be sure the pin goes through the neutral safety switch.
5. Insert long quick release pin in the wide end of the shifter. Due to slight misalignment in some shifters the shifter pivot shaft may need to be reamed so that the quick release pin will slide through easily.

