

## ***Installation Instructions for 80360, 80361 & 80362 E-Track***

### **Installation Instructions:**

1. These systems can be welded, riveted, or bolted to a trailer wall or floor. When mounting to the floor use Grade 8 bolts fastened through the trailers cross members adding additional fasteners every 3 holes.
2. Mount on a smooth flat surface. Not recommended for use on diamond plate.



**1-800-345-4545 [jeps.com](http://jeps.com)**