

Installation Instructions for 81070 On Board Dragster Air Compressor

Drain after every race weekend.

Find a flat surface to mount unit to. It can be mounted in any direction but upside down.

We recommend NOT to mount unit in driver's compartment. In a Door Car the trunk is a good place. In a Dragster, in front of the foot box is recommended.

Mark the four mounting holes using the pattern included in this kit. Use a 'H' drill bit to drill holes.

Mount the four feet to bottom of mounting plate. Install unit and tighten nuts.

Remove CO2 bottle and install air line from CO2 bottle to your JEGS system using the 1/4" compression fitting on top of regulator.

Wire the Red wire to 12 volt source with at least a 15 amp switch. Ground the Black wire to good ground.

Turn your unit on. Let it pump up and check complete system for leaks.

Take a spray bottle with soap and water in it and spray all fittings to check for leaks. Your system will work to its maximum performance with no leaks.

Regulator is set from the factory and is tested at 90 lbs. System may vary, check gauge after you install and have cycled the system a couple of times.



