

Installation Instructions for W2935

Wire Insertion Tool

Piercing

Some vehicles offer a blank grommet on the firewall to use for adding accessories. Power for these electrical accessories can come from the battery, or outside the vehicle using power from the fuse block inside the cab. If one is not available use the steps below...

1. Follow the wires from the fuse block under the dash; you'll see a rubber grommet at the firewall.
2. Carefully pierce the grommet; just be cautious of the existing wires under the dash and in the engine compartment.
3. Once you're through the firewall pass the needed wire through the hole on the end of the tool.
4. Go to the engine compartment and draw enough wire to make the necessary connection.
5. Now go back under the dash and estimate the wire needed, make the cut and pull the piercing tool out of the grommet.
6. If needed add a little silicone to seal the hole.



1-800-345-4545 jeps.com