



# ***JET Power-Flo***

## **Throttle Body Spacer Installation Instructions**

### **2004-2007 Ford F150 5.4L**

### **Part #62130**

1. Remove throttle body air intake assembly from the throttle body.
2. Remove the (4) four factory bolts from the throttle body.
3. Install the JET Power-Flo throttle body spacer using the supplied o ring.
4. Replace the four (4) bolts that mount the throttle body to the intake manifold using the four (4) new bolts and four (4) flat washers supplied in the kit.
5. Replace the four (4) bolts that mount the air intake assembly using the four (4) supplied spacers (use these between the intake air the air box) and the four (4) flat washers.
6. For vehicles that have them verify the throttle linkage, cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.
7. Reinstall the Air Intake assembly.

#### **PARTS LIST:**

- (1) JET Power-Flo Spacer
- (1) O-Ring Seal
- (8) 6mm x 45mm Bolts
- (8) 6mm Flat Washers
- (4) Spacers

#### **TOOLS NEEDED:**

- (1) 10mm Socket
- (1) Ratchet

**JET Performance Products**  
17491 Apex Cir.  
Huntington Beach, CA 92647  
Tech: 714-848-5515 Fax: 714-847-6290  
[www.jetchip.com](http://www.jetchip.com)  
[customerservice@powerbyjet.com](mailto:customerservice@powerbyjet.com)