



## **POWR-FLO MASS AIR SENSOR INSTALLATION INSTRUCTIONS**

(Note: Your application may look slightly different but installation is generally the same)

### **1. Locate stock Mass Air Sensor, loosen hose clamps and unplug wiring.**



### **2. Remove Intake Hose and remove stock Mass Air Sensor**



### **3. Remove gasket from stock Mass Air Sensor and install on Powr-Flo Sensor**



**4. Install JET Powr-Flo Sensor, tighten all clamps and plug in harness**

**Note: Some applications come with a adapter harness, this will plug into your factory harness. Only use if your application originally had a three wire harness.**



**5. Start vehicle make sure vehicle runs smoothly with no check engine lights.**

**6. If check engine lights come on double check installation, if light still comes on replace stock sensor and make sure light goes out when put back to stock.**

**Call customer service at 714-848-5515.**