



## **Installation Instructions Part # 69121 and 69122**

- 1. Disconnect the negative battery cable.**
- 2. Disconnect the Mass Air Flow sensor connector from the sensor.**
- 3. Remove the air intake assembly as a complete unit by loosening the clamp and the two latches that hold down the air box lid.**
- 4. Install the new JET Mass Air Flow sensor onto the air intake. Make sure the arrows on the sensor are pointed towards the engine. Install the black sleeve that is included in the kit to the Mass Air flow Sensor and tighten down the clamps.**
- 5. Install the air box and the Mass Air flow assembly back in the car.**
- 6. Plug in the new Mass Air Flow sensor harness that was supplied in the kit to the new sensor and plug the factory harness into the other end. Make sure to take notice of the alignment locks and don't force the connectors together if they are not aligned, they lock together.**

**If you have installation questions or problems please contact our technical department at (714) 848-5515 we are available Monday thru Friday 8am-5pm P.S.T.**