



**BRACKET KIT #14700**  
**RUNNING BOARD INSTRUCTIONS**  
1999-2006 TOYOTA TUNDRA  
QUADCAB & SEQUOIA

---

INCLUDED	
Running Board	2
Brackets	8
Bolt Pack	2

  

NECESSARY TOOLS	
Ratchet wrench with 1/2" & 13mm socket	
Combination wrench	
Safety glasses	

**CAUTION: BEFORE BEGINNING THIS INSTALLATION PROCEDURE, READ THROUGH INSTRUCTIONS CAREFULLY AND COMPLETELY**

**Step 1:** Determine proper bracket placement

**Step 2:** There are (6) factory holes. Remove black foam tape from holes (front to back #2,#3,#4,#6) to reveal hole on the underside of vehicle where the brackets need to be placed. (4) brackets per side.

**Step 3:** Loosely bolt (hand tighten) brackets on using 5/16" bolts and nuts. Be careful not to drop in hole and lose them.

**Board Installation & Check**

**Step 1:** Place board on brackets by sliding mounting bolts in slots on underside of boards and allow bolt thread to drop through bracket slots with bracket mounted in position slide 5/16"bolts down outside channels on underside of board so bolt stud will line up with bracket slots & install board on brackets to see if board is level.

**Step 2:** Check board for levelness and snug fit to vehicle. Tighten outside brackets first then adjust inside bracket accordingly. Adjust and full tighten all brackets.

**Step 3:** Check all bolts to verify completed mounting and tightness. Installation is complete.

Rampage Products  
22420 Temescal Canyon Rd Unit C  
Corona, CA 92883  
Phone: (951)277-4949 Fax: (951)277-2295  
[www.rampageproducts.com](http://www.rampageproducts.com)