

# POP & LOCK®

## CCEX 6

This harness is required for trucks that have an eight foot box and a crew cab. This harness is designed to give you the extra length required to install tailgate power lock.

### Installation:

After installing the short tailgate harness that came with your tailgate lock, connect one end of the harness that came with your extension kit to the tailgate harness and run it under the bed of the truck tying it up with the cables supplied. Next connect the long harness that came with the power tailgate lock with the connector on the extension harness.