

campright™ rightline GEAR

SUV Tent with Screen Room Set Up Guide

Setting Up The SUV Tent

1-Clear sharp rocks and sticks from the ground. Lay out the tent on a smooth flat surface.

2-Connect the (4) sections of the steel pole together using the (3) junctions (Fig 1 and Fig 2) as follows:

- Place the long steel pole section over the main tent and place the shorter steel pole section over the screen room. Connect these two pole sections with the junction that is marked with the letter “M”.
- Place the (2) steel pole sections with black plastic caps over the awnings on each end of the tent. Connect these pole sections to the main pole sections with the junctions that are marked with the letter “A”.



3-Thread the (6) fiberglass poles through the pole sleeves and connect them to the (3) junctions (Fig 3). The fiberglass poles will lay across the tent (Fig 4).



4-Attach the tent clips to the steel poles (Fig 5).



WARNING:
Make sure the fiberglass poles are pushed all the way into the pole junctions before raising the tent.

5-Place the ends of the steel pole into the pockets at the end of each awning (Fig 6).

6-Raise the tent by bending the black fiberglass poles and placing their ends over the corresponding pole pins (Fig 7).

WARNING:
Don't use excessive force when raising the tent poles. If there is resistance check to see that the pole sleeves can slide over the poles without hang-ups.



7-Attach the tent clips to the black fiberglass poles once all the poles are raised (Fig 8).

This tent has a lower sleeve and an upper sleeve which create an alligator clamping action on the rear of the vehicle.

8-Back the vehicle close to the tent, bumper touching, and place the upper sleeve over the opened rear door (Fig 9).

9-Buckle the (2) short straps on the leading edge of the upper sleeve around the vehicle's roof rack rear cross bar (it may be necessary to adjust the position of the cross bar.) If you do not have a roof rack, clip the (2) long strap pieces provided into the short straps' female buckles and attach the “J” hooks to the windshield wipers (Fig 10).



10-Adjust the baffle inside the top edge of the upper sleeve to keep water, wind, and bugs out.

11-Make sure the lower sleeve is sitting above the vehicle's muffler. Place the (2) adjustable straps of the lower sleeve over the top of the vehicle's rear hatch (Fig 11).



12-Raise the hatch, making sure the straps are tight when it reaches the top.

13-Attach the straps on the lower sleeve to the inside of the vehicle's cargo area (Fig 12).

14-Attach the “J” hooks of the side straps (A) and (B) to the vehicle’s wheel well and tighten.



15-Run the lower strap (C) under the rear wheel well and route it up to snap onto the upper strap (D) (Fig 13).

16-Repeat steps 11 and 12 on the other side of the vehicle.

17-Stake the corners, sides, and guy lines of the tent (Fig 14)



To have use of the vehicle for the day, simply disconnect the upper and lower sleeves and zip up the door leading to the SUV. The upper and lower sleeves are secured to the tent body by the dowel and loop fasteners around the doorway (Fig 15).



Taking Down The SUV Tent

1-Detach the upper and lower sleeves and move the vehicle away from the tent.

2-Zip up all tent windows and doors and pull out all stakes, placing them in the stake bag.

3-Un-clip the poles and remove them from the pole pins, lowering the tent to the ground.

4-Disconnect and slide out all of the poles and place the pole segments back into the pole bag.

5-Fold the tent into thirds across the width of the tent. Fold the tent in half lengthwise and in half lengthwise again.

6-Place the pole bag and stake bag in the middle of the folded tent and roll up the tent before placing it back into the storage bag.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC

This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame resistant properties ineffective.

Visit: www.rightlinegear.com

LIMITED WARRANTY

Rightline Gear warrants that for one (1) year, from the date of purchase that all PackRight and CampRight products will be free of material defect and Rightline Gear will repair or replace any defective or damaged product free of charge if it is returned in original condition by the consumer to Rightline Gear or the place of purchase. Claims of defective material and/or workmanship must be made in a timely manner. Safe and maintenance-free use of this product depends upon the consumer's or user's proper installation of the product and good judgment in its use. Rightline Gear is not responsible for the consumer's or user's use or misuse of this product. Damage to Purchaser's vehicle or any other vehicle caused by Purchaser's improper use of this product may cause serious injury or death. The Purchaser acknowledges that Rightline Gear has no control over the attachment of its products to vehicles or the attachment of items to the Rightline Gear products. Accordingly, Rightline Gear cannot assume responsibility for any damage to any property arising out of the improper attachment or use of its products.

RIGHTLINE GEAR SPECIFICALLY DISCLAIMS ANY AND ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY AND WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. RIGHTLINE GEAR FURTHER DISCLAIMS ANY WARRANTY OR OTHER PROMISE THAT GIVES RISE TO ANY SORT OF CONSEQUENTIAL, EXTRAORDINARY, PUNITIVE, EXEMPLARY, SUBSEQUENT, OR NONECONOMIC DAMAGES OR ATTORNEY FEES. THE CONSUMER OR USER'S SOLE REMEDY AGAINST RIGHTLINE GEAR FOR ANY DEFECT IN THIS PRODUCT IS LIMITED TO FULL RETURN OF THE PURCHASE PRICE.

RIGHTLINE GEAR SPECIFICALLY ENCOURAGES COMPLIANCE WITH ALL MOTOR VEHICLE LAWS, AND EXPRESSLY DISCLAIMS ANY AND ALL LIABILITY FOR FAILURE TO COMPLY WITH SAME.