


### 2008- DODGE CHALLENGER V6 3.5L DUALS

**Warning:** When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

**Notice:**  
For this exhaust system to work correctly with the V6 Challenger the consumer should purchase the V8 Challenger rear valance which has provisions for the second exhaust tip. The Dodge part numbers are as follows.

**Valance:** 68039501-AB  
**Hardware (Rivets):** 6500859



**Step 1:** (Carefully read all instructions before installation) Disconnect the vehicle's battery before removal of the OEM exhaust. This will allow the computer to reset itself with the new system, and prevent electrical accidents. Begin loosening the existing OEM exhaust system by loosening the OEM clamps located behind the catalytic converters. Remove the welded hangers from the OEM rubber insulators. Do not damage the OEM rubber insulators, as they will be reused to install the new exhaust system. The OEM exhaust system can be cut behind the mid muffler to aid in the removal of the OEM exhaust system.

**Step 2:** Install the new exhaust system using a front to rear method. Using two supplied 2.25" clamps, install the front Y-pipe assembly. Leave all fasteners loose for final adjustment of the complete system. Using a supplied 2.50" clamp, install the Mid muffler assembly. Complete the installation of the Mid muffler assembly by fitting the welded hanger into the OEM rubber insulator. Using a supplied 2.50" clamp, install the rear Y-pipe assembly. Using a supplied 2.25" clamp, install the passenger's side muffler assembly. Complete the installation by fitting the welded hangers into the OEM insulators. Fit the driver's side muffler assembly into place for a mock up fitment (see Dia. 1). This will help determine the location of the supplied hanger bracket. Install the front and rear hanger brackets using the supplied bolts as shown on diagrams 2 and 3. Using a supplied 2.25" clamp and rubber insulators, install the driver's side muffler assembly. Complete the installation by inserting the rubber insulators onto the hangers brackets and the welded hangers.

\*MAGNAFLOW Performance Exhaust recommends professional installation on all their products

Technical support: 1-800-959-9226 ext. 4500

### 2006- DODGE CHALLENGER V6 3.5L



Dia. 1



Dia. 2



Dia. 3

**Warning:** When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

**Step 3:** With all components mounted loosely, adjust the system for overall aesthetics and clearance of frame & bodywork. (MAGNAFLOW recommends at least 1/2" of clearance between the exhaust system and any body panels to prevent heat-related body damage or fire.)

**Step 4:** Once a final position has been chosen for the new system, evenly tighten all fasteners from front to rear. The supplied band clamps must be VERY tight to properly align the pipes and prevent leaks (approximately 65ft. lbs.) Inspect all fasteners after 25-50 miles of operation and retighten if necessary.