



INSTALLATION INSTRUCTIONS



2015 CHEVROLET 2500HD 6.6L

PART NO. 17857

BILL OF MATERIALS:



- 1. Y-PIPE ASSY
- 2. OVER AXEL PIPE D/S
- 3. OVER AXEL PIPE P/S
- 4. TAIL PIPE ASSY



WEAR SAFETY GLASSES



READ INSTRUCTIONS THOROUGHLY BEFORE INSTALLING PRODUCT

SHOP SUPPLIES:



SPRAY LUBRICANT

To ease removal of existing exhaust components (especially on older vehicles) spray penetrating lubricant on all fasteners and hangers/insulators that will be loosened or removed and let soak before disassembly.

HARDWARE KIT:

- 1.[4] 3.50" Clamp
- 2.[1] 4.00" Clamp

MINIMUM REQUIRED TOOLS:



15mm



Hanger Tool (Or Pry Bar)



SAWZALL, SIMILAR CUTTING TOOL

MAGNAFLOW RECOMMENDS PROFESSIONAL INSTALLATION ON ALL THEIR PRODUCTS



WARNING: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

ATTENTION: Always install any supplied band or U-bolt clamps to the proper torque specifications of 40-45 ft-lbs for band clamps and 30-35 ft-lbs for U-bolt clamps. Over tightening will result in the clamp breaking and will NOT be warranted by MagnaFlow.

INSTALLATION INSTRUCTIONS



Step 1. To begin the removal of the OEM system you will need to cut 18.25" behind the DPF. You can then disengage the welded hangers from the rubber insulators, working rearward finish removing the system. Do not damage or discard the rubber insulators, as they will be reused to mount the new system.



Step 2. Begin installation of the Magnaflow system by first clamping the Y-pipe inlet to the newly cut outlet of the DPF using the supplied 4.00" clamp. Then attached the Over Axel pipes to the Y-Pipe Assy using the supplied 3.50" clamps and fitting the hangers in the rubber insulators (leave all clamps loose for final adjustment of the complete system).



Step 3. Next Install the Tail Pipe Assembly to the Over Axel Pipes in a similar fashion using the supplied 3.50" clamps and by fitting the welded hangers into the rubber insulators.



Step 4. Once a final position has been chosen for the new exhaust system, evenly tighten all clamps from front to rear using the torque specifications on page one of the instructions. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.