

Rear Coil Spring Spacer

Read all instructions thoroughly from start to finish before beginning installation

NOTE: Some of the installation steps may not apply to your vehicle. For specific information, obtain an original equipment service manual. Do not reuse OE insulators for Nissan Pathfinder and Armada.

1. Park vehicle on a level surface and chock front wheels. If equipped, disconnect the track bar and sway bar end links from the rear axle.
2. Raise the rear of the vehicle and support the frame with jack stands. Remove the rear wheels.
3. Reference mark the location of the coil spring. Support the rear axle with a jack.
4. Disconnect the lower shock mount. Disconnect any cables or hoses that prevent lowering the rear axle.

CAUTION: Do not allow the axle to hang from any cables or hoses.

5. Carefully lower the rear axle. Remove the coil spring and insulator.
6. Place Rancho spring spacer on top of insulator or coil spring depending on application.
7. Insert spacer and coil spring into upper mount. Place bottom of coil spring on axle pad.
8. Align reference marks and raise axle. Reattach lower shock mount.

NOTE: New shock absorbers are required for RS70076 (Nissan Armada).

9. Repeat for other side.
10. If necessary, reconnect any cables or hoses.
11. Reinstall wheels and lower vehicle to ground. Tighten lug nuts to specifications.
12. Reattach track bar and sway bar end links if equipped. Tighten all nuts and bolts to specifications.