

# SKYJACKER®

THE BEAR OF SUSPENSIONS

## GM, Dodge, Ford, Jeep, Scout Single Steering Stabilizer Part# 7110

Part #	Description	Qty.
7800	WHITE STEERING DAMPER	1
83170	MAIN BRKT FOR 7110	1
83161	UNIVERSAL TIE ROD BRACKET	1
38X318X312U	3/8 X 3 1/8 X 3 1/2 RD/UBLT	2
516X114X134U	5/16 X 1 1/4 X 1 3/4 U-BT R	2
38CTN	3/8-16 COARSE N/I LOCK NUT	4
38SAEW	3/8 SAE WASHER	4

Part #	Description	Qty.
516CTN	516-18 COARSE N/I LOCK NUT	4
516SAEW	5/16 SAE WASHER	4
STEM BUSH-SST	STEM BUSHING-STEERING STAB.	4
142120	STAB WASH PKG - P889/145098	2
B10RS	RED BOOT	1
BTIE	RED BOOT TIE	1
HSS	HYDRO SHOCK DECAL	1

**Note:** Skyjacker steering stabilizer Part# 7110 is designed to fit several makes of vehicles covering several years. Configuration of the front end of your vehicle will determine where you mount the stabilizer. Differential cases are located either on left or right side depending on vehicle. This stabilizer can be installed on either side.

1. Park the vehicle on level ground and place the wheel in a straight forward position. Set the emergency brake and block the rear tires.
2. Install bracket "A" onto axle housing tube per illustration. Install using U-Bolts and nuts. Do not tighten at this time. Install the stabilizer onto bracket "A" using bushings and washer packs provided.
3. Install the shaft end of stabilizer to bracket "B".
4. Extend stabilizer shaft out 4.44" (exactly half way) and mount onto tie rod using U-Bolts and nuts. Rotate tie rod bracket as needed to obtain best position. Tighten all nuts securely on bolts and u-bolts at this time.
5. Rotate tires left to right and check all hardware for clearance. Re-tighten after the first 100 miles and periodically thereafter.

