

PART NOS. 84085 & 84090

Instruction Sheet

KIA / HYUNDAI REAR CAM KIT

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

Plan Ahead - Read All Instructions BEFORE installing part.

Check for loose or worn parts, proper tire pressure, and odd tire wear patterns before beginning alignment.

1. Raise vehicle and support by frame.
2. Pre-assemble SPC cam bolts by placing one cam washer onto each bolt.
3. One at a time, remove OE adjusting bolt assemblies per manufacturer's procedure and install SPC bolt/cam in same direction.
4. Place second cam washer over protruding end of each bolt and install nut, lightly tighten.

NOTE: Tightening fasteners with vehicle in raised position may cause premature bushing failure.

5. Lower vehicle onto tires.
6. Adjust alignment angles by turning head of SPC cam bolts. Once desired setting is achieved, hold head of cam bolts from rotating and tighten nuts to manufacturer's specification.
7. Complete alignment and road test vehicle.

Always check for proper clearance between suspension components and other components of the vehicle.



**Specialty
Products
Company**

4045 Specialty Pl • Longmont, CO 80504 • (303) 772-2103

For warranty information go to: www.specprod.com/warranties

www.specprod.com • Email: info@specprod.com Printed in U.S.A.

Toll Free Technical Hot Line: 1-800-525-6505

ECN#2674

©2019 Niwot Corp. dba Specialty Products Co. • Form No. 84085INS • Rev. 5/19