



YJ WINDSHEILD LIGHT BRACKETS

Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

KIT CONTENTS

Driver Bracket (1)
Passenger Bracket (1)
Gaskets (2)
Button Head Bolts(4)

TOOLS NEEDED

T40 Torx
6mm Allen Wrench

INSTALLATION INSTRUCTIONS

1. Using a T40 torx bit remove the two factory bolts on the driver window hinge. **See Photo 1.**
2. Install gasket on the back side of the light bracket as shown in **Photo 2.**



3. On top side of the hinge and secure bracket with the supplied 5/16+bolts and a 3/16qallen wrench. **See Photo 3.**
4. Install the Led Light with the supplied instructions. **See Photo 4.**



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

Thank You for choosing Rough Country for your off road needs!!!