

**Air Filter**  
**1998-02 Camaro/Firebird "Blackwing" High-Flow**  
**C4 Corvette "Blackwing" High-Flow**

PACKING LIST

*Before installation, use this check list to make sure all necessary parts have been included.*

ITEM	QTY	CHECK	PART NUMBER	DESCRIPTION
1.	1	<input type="checkbox"/>	662118	Filter Assy w/Tray
2.		<input type="checkbox"/>	*****	Instructions

**INSTALLATION INSTRUCTIONS - #25012B**

- 1 This filter comes with a new tray to be used with all 1998-2002 Camaro/Firebird.
- 2 Before installing the tray into your airbox base, snap off the plastic handle on the front side of the tray and trim any excess plastic flush with the front edge.
- 3 This tray will not be used on any C4 corvette using the SLP high flow filter.