



1501 Industrial Way North, Toms River, NJ 08755
Phone: (732) 349-2109 • Fax: (732) 244-0867

PART #31035

2000-02 Camaro/Firebird Stainless Replacement Y-Pipe

PACKING LIST *Before installation, use this check list to make sure all necessary parts have been included.*

ITEM	QTY	CHECK	PART NUMBER	DESCRIPTION
1.	1	<input type="checkbox"/>	310610116A	Pipe, D-Side, Front, W/Ball Flange
2.	1	<input type="checkbox"/>	310610116B	Y-Pipe, Short, 2000-2002, LS1 F-Body
3.	1	<input type="checkbox"/>	31035K	Install Kit
4.	1	<input type="checkbox"/>	*****	Instructions

WARNING: SLP recommends wearing safety glasses for the complete installation.

WARNING: SLP recommends allowing the vehicle to cool (not running) for five hours before beginning the installation. SLP recommends wearing safety glasses for the complete installation.

WARNING: Too avoid the chance of electrical shock or damage to your vehicle's electrical system, disconnect both the negative and positive battery leads (in that order) at the battery.

INSTALLATION INSTRUCTIONS - #31035

1. Disconnect the negative battery cable.
2. Raise and support the vehicle. A vehicle lift is highly recommended for this installation.
3. From the under side of the vehicle loosen band clamp at the joint where intermediate pipe joins the outlet of the O.E.M. Y-pipe. Remove the brace that hangs below this joint. Slide the intermediate pipe and muffler assembly rearward until the slip joint comes apart.
4. Loosen and unbolt each of the two flanges at the catalytic converter assembly outlets and remove the OEM Y-Pipe from the vehicle.
5. Next install the driver's side elbow onto the outlet of the flange at the catalytic converter assembly.
6. Next install short Y-Pipe onto the outlet of the driver's side elbow and onto the outlet of the passenger's side flange at the catalytic converter assembly.
7. Used the supplied clamp to secure the driver's side elbow to the short y-pipe.
8. Slide the muffler assembly and intermediate pipe forward.
9. Check for clearances to all body parts and tighten down each clamp, nut and bolt.
10. The installation is now complete.