



## **CAUTION!**

**Chrysler 318-360 C.I.D. engines using  
WEIAND 8007, 7545, 8022, 1995, or 8015**

Do not use OEM style metal gaskets. Use only soft composition type .050 / .060 thick will work with an aluminum manifold. The factory dowel pins located in the front and rear cross-section of the tappet valley may not have to be removed. Just be careful that they do not interfere with the proper seating of the manifold on all surfaces.

**W521**



## **CAUTION!**

**Chrysler 318-360 C.I.D. engines using  
WEIAND 8007, 7545, 8022, 1995, or 8015**

Do not use OEM style metal gaskets. Use only soft composition type (.050/.060) thick will work with an aluminum manifold. The factory dowel pins located in the front and rear cross section of the tappet valley may not have to be removed; just be careful that they do not interfere with the proper seating of the manifold on all surfaces.

**W521**



## **CAUTION!**

**Chrysler 318-360 C.I.D. engines using  
WEIAND 8007, 7545, 8022, 1995, or 8015**

Do not use OEM style metal gaskets. Use only soft composition type (.050/.060) thick will work with an aluminum manifold. The factory dowel pins located in the front and rear cross section of the tappet valley may not have to be removed; just be careful that they do not interfere with the proper seating of the manifold on all surfaces.

**W521**