

## **Installation Instructions for 027-13301K Fitting Kit for Aeromotive Regulator 13301**

### **Kit Includes:**

- (1) 555-110403 3/8" NPT Port Plug(s)
- (2) 555-110106 3/8" NPT to #6AN Outlet Fittings
- (2) 555-110107 3/8" NPT to #8AN Inlet & Return Fittings

NOTE: Fittings require the use of teflon thread tape or sealant prior to installation.

