

Installation Instructions for 100285, 100286 & 100287 Pressure Test Kit

Installation Instructions:

NOTE: This kit is designed to use either compressed air or Nitrogen.

1. Apply liquid Teflon thread sealant to the 1/8" NPT side of the air valve fitting.
2. Thread the air valve fitting into the appropriate AN adapter size required for the pressure test and tighten.
3. Screw the air valve/AN adapter assembly into one end of the line being tested.
4. Screw the appropriate AN plug into the other end of the line being tested.
5. Using a standard tire chuck pressure check the line by starting at a low pressure and slowly increasing to the operating system pressure.

