

Installation Instructions for 15417 Throttle Body Spacer

Installation Instructions:

1. With engine off remove air cleaner assembly from top of throttle body unit.
2. Using a 10mm socket remove mounting bolts from the throttle body unit. Remove throttle cables & wire connectors. Now remove throttle body. Clean off old gasket.
3. Remove the 2 or 3 bolts from throttle linkage bracket.
4. Install throttle body spacer with gaskets on either side, then the throttle body unit, bolt down with bolts supplied in kit. Torque to 6 ft.lbs.
5. Install spacers under the linkage bracket and bolt down with bolts supplied.
6. Install throttle linkage & wire connectors.
7. Inspect throttle for open & closed travel, then reinstall air cleaner housing.
8. Start engine & let idle for a couple of minutes then go drive. It may take 15 minutes of normal driving for the computer to relearn.



1 Throttle Body Spacer

2 Throttle Bracket Spacers

State of California
Air Resources Board
Executive Order D-623
Exemptions