

## ***Installation Instructions for 60540***

### ***Lower Torque Box Plates***

Fits: 1979 to 1995 Ford Mustangs

**WARNING!** Disconnect the negative battery cable before welding or computer failure can occur.

**CAUTION!** Rear springs are under pressure please consult a factory service manual or certified technician for appropriate removal procedures.

#### **Installation Instructions:**

1. Jack the car up and secure it with jack stands under the frame. The rear end should move freely up and down.
2. Disconnect negative battery cable from the battery.
3. Consult a factory service manual for the procedures to remove the rear lower control arms and springs.
4. With the control arms out of the way, mock up the reinforcement plates on the lower torque boxes. Note any trimming the may need to be done.
5. Clean and prep the metal, then tack in place with several spot welds around the perimeter in a star type pattern.
6. Finish weld plates and paint over any exposed metal and welds to prevent rust.
7. Reassemble the rear springs and control arms.



**1-800-345-4545 [jeps.com](http://jeps.com)**