

Part #133 8-12-2005

This bar is designed to replace your present anti-sway bar with no modification necessary. As you can see, the bar is similar; the only change on some bars is a modification of the contours made necessary by the increase in bar diameter. This bar uses the original hardware now on the car (bushings, clamps, end-links, etc). If the existing hardware components are badly worn, replacements may be obtained from your O.E. dealer.

After installation, bounce the car to check clearance of all parts throughout the suspension travel distance. After checking the above, and that all fastenings are of suitable tightness, road test the vehicle and accustom yourself to the vehicle's new handling. For best performance, handling, and more neutral steering, this kit should be used in conjunction with our rear kit. As we cannot supervise your installation, or driving, we cannot be held responsible for more than the cost of the kit.

Hardware:

2 RH 013 End-links 2 RH 040 Brackets 2 RH 509 Bushings