



310-509 INSTALLATION INSTRUCTIONS 03-07 Jeep Grand Cherokee 4.7L

Thank you for purchasing the PowerAid Throttle Body Spacer. Please read the instruction manual carefully before proceeding with the installation. Contact AIRAID @ (800) 498-6951 8:00 AM - 5:00 PM MST Weekdays for questions regarding fit or instructions that are not clear to you. Your PowerAid Throttle Body Spacer was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, please contact AIRAID.

Thank you for selecting AIRAID.



Included with your Poweraid Spacer is a sticker with a California Air Resources Board (C.A.R.B.) Executive Order (EO) number. This sticker must be placed in plain view inside of the engine compartment. Failure to do so may prevent you from passing a smog inspection.

*** Also available for your 99-04 Jeep Grand Cherokee– the Airaid Intake System P/N 310-127.**

Parts List

- (1)- Power Plate
- (1)- "O"-Ring #240
- (3)- Hex Bolts 6mm x 60mm
- (5)- Flat Washers 6mm
- (2)- Air Box Extension Plates
- (2)- Hex Bolts 6mm x 20mm
- (1)- Throttle Cable Bracket
- (2) .636 long w/ 3/8" hole Spacers
- (2) 3/8-16 x 1 1/2" bolts
- (1) Nutplate

Tools List

- 1/4 in. Ratchet
- 1/4 in. x 12 in. Extension
- 8mm Socket
- 10mm Socket
- 14mm Socket
- 14mm Box End Wrench
- 3/16 Allen Wrench
- 5/32 Allen Wrench
- 7/8 Box End Wrench

Installation Instructions. Read Me!

- 1. DISCONNECT NEGATIVE (-) BATTERY CABLE.**
2. Remove air intake hose assembly.
3. Remove throttle body air intake box and save bolts.
4. Remove (3) bolts from the throttle body.
5. Unclip throttle & cruise cables and remove from manifold and throttle lever.
6. Install throttle & cruise cable bracket and tighten bolts. (**Ref. "B"**)
7. Install both throttle & cruise cables thru reinforcement ring of throttle cable bracket. Then slide and lock both plastic cable retainers into slot separately.
8. Install power plate using (3) 6mm x 60mm bolts and flat washers. (**Ref. "A"**)
9. Reattach cruise and throttle cables to throttle body lever.
10. Locate (2) air box extension brackets (one right & one left hand) using (2) 6mm x 20mm bolts, (2) 6mm washers, and air intake box using saved bolts. (**Ref. "C" and Step 3**)
11. Inspect & Test throttle linkage for full Open & Closed travel before driving. Some cruise and kick down cables may require adjustment. Please refer to vehicles service manual for proper adjustment.
12. Reinstall throttle body air intake assembly using **Step 2** as an example.
13. Reconnect battery cable. Enjoy!

The sound of power...The "whistle" means its working!



- Ref. "B"** (1) Throttle Cable Bracket
(2) .636 long w/ 3/8" hole Spacers
(2) 3/8-16 x 1 1/2" Bolts
(1) Nutplate



- Ref. "C"** (2) Air Box Ext. Plates
(2) 6mmx20mm Hex Bolts
(2) 6mm Flat Washers



- Ref. "A"** (1) Power Plate
(1) "O" Ring #240
(3) 6mm x 60mm Hex Bolts
(4) 6mm Flat Washers



Rev. 07/03/07