



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

Part # 11330501
63-72 C-10 HQ Series Front Shock Kit
For Use w/ Stock Lower Arms

Shock:

2	22939999	HQ Smooth Body Shock Cartridge
4	70011138	3/4" ID Shock Bushing
2	90002102	1/2" ID Inner Sleeve
2	90002103	5/8" ID Inner Sleeve

Components:

2	90001617	Shock Stud
---	----------	------------

Hardware:

2	99501003	1/2"-13 x 2 1/2" Hex Head Bolt
2	99502001	1/2"-13 Nylok Nut

Installation Instructions



1. Replace the factory upper shock stud with the new one supplied.
2. Fasten the shock to the upper stud.
3. Fasten the shock to the lower arm using the factory hardware.