



ALL69006

1979-04 Mustang Driveshaft Loop

INSTALLATION INSTRUCTIONS

Contents:

- Top Safety Loop (x1)
- Bottom Bar (x1)
- 3/8" x 1-1/4" Bolt (x12)
- 3/8" Flat Washer (x12)
- Nyloc Hex Nut (x12)

CAUTION: Do not begin installation until vehicle is fully supported and secure.

NOTE: It is not necessary to remove the driveshaft or exhaust when installing this product.

Installation:

1. Pull back interior carpet and padding to obtain access to floor pan for installation of mounting bolts. This will typically require removal of door sill molding, seats and front kick panels.
2. Raise vehicle to desired work height and fully support for safety and security. Installation may be easier if the rear axle is permitted to hang with suspension unloaded.
3. Rotate the Top Safety Loop around the driveshaft and into position. Slide into position approximately 4" behind the front u-joint. Position the Bottom Bar with center offset up and holes for the Top Safety Loop offset to the passenger side.
4. Using supplied nuts and bolts, attach the Top Safety Loop to the Bottom Bar and tighten securely. For maximum exhaust clearance, it is recommended to install the bolts from the bottom and the nuts from the top.
5. Confirm there is no interference with the driveshaft or exhaust. Position the mounting ends flat against the floor pan.
6. Mark holes and drill using a 3/8" drill bit.
Caution: Be careful not to damage any vehicle components during the drilling process.
7. Using supplied hardware, bolt the assembled loop to the floor pan. Use supplied flat washers inside vehicle on top of floor pan and tighten securely. Note: Some later models may require a 3/8" spacer (not included) to level the bracket.
8. Re-check driveshaft and exhaust clearances before lowering vehicle. Re-install interior components.

Allstar Performance 8300 Lane Dr., Watervliet, MI 49098
Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com