

# **NOTICE:**

**FOR APPLICATIONS WHERE OEM COIL AND BRACKET ARE RIVETED TOGETHER. REMOVE OEM COIL AND BRACKET AS AN ASSEMBLY. DRILL OUT OR GRIND OFF RIVET HEADS AND REASSEMBLE ACCEL SUPER COIL AND OEM BRACKET WITH HARDWARE KIT INCLUDED.**

**FORM NO. 3/794/95A**

#140024

GM HEI Remote Mount 1996-01 Super Coil